

Production Booklet

for

CHANDLER SPA

2800 Richter Ave. Suite C, Oroville, CA 95965 • voice: (530)534-9910 fax: (530)534-9915 • email: sales@tiledspas.com • website: www.tiledspas.com



RECOMMENDED MAINTENANCE

Please Note:

These are only recommended guidelines to care for a Nespa all tiled spa. Local codes may require additional procedures, therefore consult with a pool professional that is LA county Health Department ceritfied for more information on local codes and requirements.

SPA SURFACE

Your spa tile is acid resistant and frost-proof. The Tile does not absorb germs or algae. Tile does not stain and is very easy to clean. Color does not fade or loose its luster. All grouts are epoxy based and are extremely durable. To remove scum line use soft nylon brush and small amounts of biodegradable soaps. Do not use abrasive brushes or chemicals.

MAINTENANCE

A. CHEMICALS:

- 1) It is important to maintain a chlorine residual of 2 PPM in the spa. That residual can be provided by chlorine or bromine.
- 2) It is recommended to use Bromine or dichlor (granular) forms of chlorine. If bromine Tabs are used we suggest floating or inline dispenser.
- 3) Never use acid to lower Ph in the tile spa.
- 4) Never use trichlor chlorine (1" or 3") tablets in the Nespa spas.
- 5) Never place tablets in skimmer basket.

B. DRAINING THE SPA:

- 1) It is recommended to drain the spa at least once every 2 months depending on bath load and water clarity.
- 2) The spa should be drained through valve exiting re-circulation pump in the spa equipment room or sump pump.
- 3) Note: Use caution to drain spa in the winter months or rainy season when water table is at its highest. It is possible for the spa to float due to hydraulic pressure from surrounding water table. We advise that you consult with your local spa specialist prior to draining the spa.

C. SPA EQUIPMENT:

- 1) Clean filter cartridge at least once every month, or when needed; i.e., if water clarity does not improve after several days.
- 2) Keep area free and clear from leaves and debris build-up.
- 3) Keep area free and clear from flooding.

D. SPA LIGHT:

1) Spa light has to be on GFCI circuit. It is controlled at spa side with ON/OFF.

E. TILE SERVICING:

1) Contact manufacture when servicing tile or grout. @ (530) 534-9910

SPA MODEL:

Legacy 10' x 20' DS

SPECIFIC	CATIONS
SHELL WEIGHT:	6000 LBS.
WATER WEIGHT:	28312 LBS.
TOTAL SHELL & WATER WEIGHT:	34311.8 LBS.
WATER VOLUME:	454 Cu.Ft
WATER GALLONS:	3396 GAL.
SURFACE AREA:	194.5 SQ. FT.
ICC ES LISTED #:	PMG-1161



Compliance with the following codes:

- 2018, 2015, 2012 and 2009 International Swimming Pool and Spa Code


- 2015, 2012 and 2009 Uniform Swimming Pool, Spa and Hot Tub Code

*Uniform Swimming Pool, Spa and Hot Tub Code is a copyrighted publication of the International Association of Plumbing and Mechanical Officials

Compliance with the following standards:

IAPMO/ANSI Z124.7-2013, Prefabricated Plastic Spa Shells

ANSI/APSP/ICC-3 2014, Permanently Installed Residential Spas and Swim Spas (formally ANSI/NSPI-3 2014)



3 0 .0 2'-2" 0 0 0 0 0 6 . . 36" 0 1.4 Waterproof Skid Support Structure attached to spa at Nespa factory ۳

APPROVED

ALL DIMENSIONS SUBJECT TO 1/4" TOLERANCES

Job #30

These drawings, concepts, and details contained herein are the original proprietary designs of <u>NESPA ENTERPRISES INC.</u>, developed over many years of experience in the industry and as such are protected by the copyright laws of the United States Government. Reproduction of any of the above without written permission to do so by <u>NESPA ENTERPRISES INC.</u>, is illegal

 $10\frac{1}{2}$

3'-6" ID $10\frac{1}{2}$ " $10\frac{1}{2}$ "


 $10\frac{1}{2}$ "


5


Location of cup anchors not to exceed 3" away from vertical riser wall

4'-3" OD

ô	TiledSpas	If printing as a PDF: Page Scaling: None	SCALE 1/2" = 1'	DWG SIZE	DWG TYPE SD
	nespa	DWG NAME 11525 CHAN	NDLER	DATE 8/28/2018	SHEET PAGE 1 OF 9







ітем 1 2 3 4 5 6 7 8 9 10 9 10	CODE SS BS MD EQ J# WF UL HR CA PB		EQUIPMENT LIST DESCRIPTION SUPACE SKIMMER - AUTOMATC WEGULZER, NESF APPROVED Paramount SDX. 107 Neur J COM 39 - 1 3 201 Higg Veib Approved. Sdately, Denni Complexe Veib Approved. Sdately, Denni Complexe Mark DRAN ADVISIA Sdately, Denni Complexe Mark DRAN ANSI J ASBAT Complexe Automatic Sdately, Denni Complexe Mark Drank Sdately, Denni Complexe Sdatel and Dody entrapment Statel and Dody entrapment Statel and Dody entrapment Stately and Dody Net J Veib Veib Mark DRAN ANSI J ASBAT Complexe Autor J Approved Distance Mark Drank Sdately, Denni Complexe Mark Drank Sdately	CATALOG NO. SP-1084FVE 004-182-2212-01 32CDFLFR101 6HPHAxxx 10-5100 10-3500 10-3500 10-3500 GLO-BRITE P-Rail PS-6019-BC PB-2008 MP 1953 J	QTY. 3 4 2 4 20 4 1 2 2 4 1 2 4 1 1	CA CA ME	UL WI	CA CA	J 1 EQ EQ J 20	J 2	EQ J 3 J 4 EQ J 17 J 18	J 5 BS J 16	J 6 J 7 MD Nespa - Aquastar sump approval IAPMO 5P-4900 MD CCCC M 15 M 15	J 8 B: -9 -9 -9 -9 -9 -9 -9 -9 -9 -9 -9 -9 -9	J 9 WF UL J 10 UL J 11 VI J 12	
	<u>A</u>	PPRO\	/ED							Page Scaling N	ng as a PDF: ☞ ▼ 25 CHANDLE	-	DWG SIZE	C 8/2018	DWG TYPE SHEET PAGE 5	EQ OF 9









Boster Pump "A" 4" Suction

- 27



Pentair LED Light #2

-

Booster Jet Return Bank "B"

Booster Suction "B" 4"

Pentair Light 1" conduit

-

Jet Bank B air Venturi 1.5" inlet

Jet return Booster bank "B"


Suction 4" Booster jet Pump "B"


Pentair Light 1"






							NOTES:
							All Equipment wired to Control Panel and then to Pool Panel
							All breakers to be GFI - use Siemens Breakers
			EQUIPMENT LIST		CATALOC		Bonding by Electrician - #8 Bare
ITEM	CODE	EQUIPMENT	DESCRIPTION	MANUFACTURER	CATALOG NO.	QTY	• Nespa installs Rail Bonds & Pool Bond
1	BP		BOOSTER PUMP: PENTAIR WFE-12 138 GPM(2)	PENTAIR	WFE-12	2	
2	FP		FILTER PUMP- PUMP: PENTAIR INTELLIFLO I2 VS 011009 2 HP (116 GPM)	PENTAIR	011009	1	
3	F	Ŷ	FILTER AND INFLUENT PRESSURE GAUGE Clean & Clear Plus Model	PENTAIR	CCP-520	1	
4	н		MASTERTEMP ASME HD400K BTU HEATER	PENTAIR	MODEL 400HD	1	Control
5	CPAN		CONTROL PANEL- PENTAIR MODEL LX 802L, WITH EMERG. SHUT OFF - 110V	PENTAIR	LX 802L	1	Image: 10 state 18" X 18" Spa Drain line Double Box Floor Sink with 6" air gap Emergency (Provided by Shut Off Plumber) Image: 10 state Single Box
6	ws		1" POTABLE WATER SUPPLY w/ 1" Zurn Wilkins Backflow Preventer	Zurn Wilkins	975XL2	1	Spa Jets Spa Light (0) (0) (0) (0) (0) (0) (0) (0)
7	СР		Chlorine Pump - ROLACHEM 25/53C Acid Pump - ROLACHEM 25/53C	ROLACHEM	25/53C	2	PENTAIR i2 Flow Chart - 011009 Auto Fill Detail Ourview Bailer Josef Calcabolis
8	сс		CHEMICAL CONTROL- Pentair Intellichem	PENTAIR	521357	1	
9	сст		CHEMICAL CONTAINMENT TANKS - Pentair Intellichem, Chlorine model 521397 and Acid model 521378	PENTAIR	521397 521378	2	y y y y y y y y y y y y y y y y y y y
10	стк		CHEMICAL TEST KIT - TAYLOR MODEL-K2000, DPD , PH	TAYLOR	K2000	1	
11	FM		FLOWVIS FLOW METER FV-C	FLOWVIS	FV-C	1	10 0 0 0 0 0 0 0 0 0 0 0 0 0
12	VG		VACUUM GAUGE	-	-	2	
							APPROVED
							If printing as a PDF: Page Steeling None VI N/A DWG SIZE DWG TYPE EQ Lavou
							11525 CHANDLER 8/28/2018 PAGE 6 OF 9







STANDARD NESPA IN-GROUND INSTALLATION INSTRUCTIONS SET-UP AND EXCAVATION

Prerequisites: Before installing your Nespa spa. You may be required to acquire a permit from your local State, County, and City building dept and or Health department. (Commercial jobs need Health Dept. Approval). Your spa installation must comply with the most current codes. (Uniform Swimming **Pool, Spas & Hot Tub Code 2006 (USPC 2006).**

Spa drawings: Request from Nespa a current spa specific construction detail, plan and section, spa plumbing detail.

Delivery Access: Clearly determine the method of getting the spa to jobsite and into the hole. This may require the use of a crane, forklift, hoist, backhoe and/or manpower etc.

1) The following instructions are general guidelines and may not apply to your specific jobsite conditions. When excavating for your spa remember to provide for plumbing and light connection clearances. In order to determine how to excavate for your spa or swim spa, measure spas outside dimension (O.D.) and add minimum 3" to all sides. This 3" clearance is to accommodate jet and suction plumbing. This 3" clearance can change or be reduced upon request. Note: skimmer location, this area may have to be larger than 3", if commercial 22".

- 2) Freeze Climates- If the spa is place into a vault (typical of freeze climates) a standard 18" or more of clearance minimum from spa perimeter should be provided. This dead air space is for possible future access to spa plumbing in case of a freeze. Area drain is mandatory. Ask your local installer for his experienced opinion. Do not hesitate to call us because we want to be sure that your installation progresses as smoothly as possible. If you have questions call us. (888) 479-4677.
- 2) **Hole depth** is determined by spa's outside height dimension. This height may vary depending if spa has skids or no skids. The spa lip may be finished or non- finished. How is the perimeter deck elevation transitioning to the spa? Focus on the finish surrounding deck elevations, thickness of the finish material on spa upper horizontal lip, equal to lip or under the spa lip. This material can be tile, stone, concrete or brick.
- 3) **Preplumb** the spa before it goes into the hole. If there are needs for electrical, bonding or control conduits run them as well before dropping in hole. Connect bond wire to niche would be best.

4) Spa should sit on level 3 ¹/₂" thick reinforced concrete pad. Sweep debris off pad prior to dropping in hole.

5) **Install spa** into the hole on top of concrete pad. Use the Eye bolts provided for crane, forklift etc. rigging. Do not hold onto pipes. Use caution with suction and jet plumbing when lowering into hole. DO NOT STRESS FITTINGS! Fill Spa with water and check for leaks prior to backfill.

- 6) Check site reference points for proper spa positioning (i.e., squaring to house, garage, etc.).
- 7) Shim to level spa. Shim with non-compression able material. Re square to house, or ref. point.
- 8) Dry pack with cement the gaps that have been created when shimming spa level.
- 9) Connect pipes to tees if spa is preplumb. Installers properly support your new plumbing from stressing spas preplumb fittings. After electrical conduit and bond wire is connected to light niche, water test spa before back filling with sand. NOTE: All Nespa products are water tested prior to leaving factory.

ELECTRICAL:

- 1) All electrical connections to spa or equipment should comply with the most recent national electrical code (NEC), state and local codes.
- 2) Connect electrical conduit to light niche. This work should be done or reviewed by a licensed electrician.
- 3) To install spa light you will need to include inside the PVC conduit to the light niche a solid #8 coated copper wire. (If you are use brass conduit, internal bond wire is not required.) This bond wire should be pulled with the light cord at the same time. This bond wire needs to be attached to the internal bonding lug of the light niche. An approved encapsulate should be applied to bond wire connection in niche.
- 4) An external #8 copper wire shall be connected to the external bonding lug on the rear of the light niche. This copper wire can then be used for additional bonding requirements (i.e., handrails or any other metallic object within 5' of the spa.

PLUMBING:

- 1) When plumbing a Nespa it is important to properly size the plumbing. We highly recommend that you follow the pump manufacturer's pipe sizing requirements and Uniform Swimming Pool, Spas & Hot Tub Code 2006 (USPC 2006). This code book is available at <u>www.IAPMO.org</u> or (909) 472 4100.
- 2) The jet air venturi should be a Hartford loop design adjacent to spa shell and air entry point can be located next to spa or remotely at equipment.
- 3) Fill spa with water and test the system for leaks PRIOR to backfilling with sand.

SAND BACK FILL:

- 1) With water in spa, back-fill around spa perimeter with dry plaster sand and wet wash with hydraulic attachment to hose. Let set for one hour and hydraulic dry again. Be sure water level in spa is at the highest level. Any questions please call us. (888) 479-4677.
- 2) If spa is free standing on elevated deck or a structure, it is important to fill spa with water and load area prior to installing coping or perimeter decking. If spa is installed in a vault situation a area drain is needed.



se drawings, concepts, and details contained herein are the original proprietary designs of NESPA ENTERPRISES, developed over many years of experience in the pool and spa industry a as such are protected by the copyright laws of the United States Government. Reproduction of any of the above without written permission to do so by NESPA ENTERPRISES, is illegal.

NESPA ENTERPRISES, Inc. LIMITED WARRANTY

This LIMITED WARRANTY covering NESPA products is extended to the ORIGINAL PURCHASER-USER BY NESPA ENTERPRISES Inc.(NESPA), 2800 Richter Ave. Unit C California 95966.

NESPA products are thoroughly inspected and tested prior to factory shipment. NESPA warrants to the ORIGINAL PURCHASER-USER that NESPA Spas and Swim Spas will be free of defect in workmanship, accessories and parts, provided said accessories and parts were manufactured by NESPA. NESPA, under this LIMITED WARRANTY, warrants only that its Spas and Swim Spas shall be structurally sound, shall retain their shape, and shall retain water for the warranty period. NESPA warrants the adhesion of tile to fiberglass for a period of three (3) years and structural soundness for ten (10) years. NESPA warrants epoxy grout adhesion for a period of three years. If any such defects appear and are reported within the warranty period, NESPA shall repair or replace such defective parts without charge if an inspection proves the claim.

The provisions of the LIMITED WARRANTY shall not apply to tile cracked, split, chipped or damaged after the product has left the factory, nor damage to tile caused by freezing nor to damage, defect, malfunction or failure to conform with the above warranty provisions where the damage, defect, malfunction or failure to conform was caused during shipment or by distributor or by unreasonable use by ORIGINAL PURCHASER-USER including improper water balance and improper sand pack or support.

This LIMITED WARRANTY shall not apply to any plumbing, equipment, or installation of spas and Swim Spas and shall not apply to any alterations made to or upon NESPA products except alterations made by NESPA employees or NESPA authorized representatives.

This LIMITED WARRANTY is expressly in lieu of all other warranties expressed or implied including the warranties of merchantability and fitness for use and all other obligations or liabilities on NESPA'S part, and NESPA neither assumes nor authorizes any other person to assume for NESPA any other liability in connection with the sale of this NESPA product. This LIMITED WARRANTY shall not apply to this NESPA product or any part thereof which has been subject to accident, negligence, alteration, abuse or misuse. NESPA makes no warranty whatsoever with respect to accessories or parts not manufactured by NESPA.

The term "ORIGINAL PURCHASER-USER" as used in this LIMITED WARRANTY shall be deemed to mean that person for whom the NESPA product is originally installed.

The LIMITED WARRANTY provided herein and the obligations and liabilities of NESPA hereunder are exclusive and are in lieu of, and buyer and original PURCHASE-USER hereby waive all other remedies, warranties, guarantees or liabilities, expressed or implied, arising by law or otherwise (including without limitation and obligations of NESPA with respect to fitness, merchantability, and consequential damages) or whether or not occasioned by NESPA'S negligence.

This LIMITED WARRANTY shall not be extended, altered or varied except by a written instrument signed by NESPA and original PURCHASER-USER.