

Production Booklet

for

Wyndham Anaheim SPAS

2800 Richter Ave. Suite C, Oroville, CA 95965 • voice: (530)534-9910 fax: (530)534-9915 • email: sales@tiledspas.com • website: www.tiledspas.com



RECOMMENDED MAINTENANCE

Please Note:

These are only recommended guidelines to care for a Nespa all tiled spa. Local codes may require additional procedures, therefore consult with a pool professional that is LA county Health Department ceritfied for more information on local codes and requirements.

SPA SURFACE

Your spa tile is acid resistant and frost-proof. The Tile does not absorb germs or algae. Tile does not stain and is very easy to clean. Color does not fade or loose its luster. All grouts are epoxy based and are extremely durable. To remove scum line use soft nylon brush and small amounts of biodegradable soaps. Do not use abrasive brushes or chemicals.

MAINTENANCE

A. CHEMICALS:

- 1) It is important to maintain a chlorine residual of 2 PPM in the spa. That residual can be provided by chlorine or bromine.
- 2) It is recommended to use Bromine or dichlor (granular) forms of chlorine. If bromine Tabs are used we suggest floating or inline dispenser.
- 3) Never use acid to lower Ph in the tile spa.
- 4) Never use trichlor chlorine (1" or 3") tablets in the Nespa spas.
- 5) Never place tablets in skimmer basket.

B. DRAINING THE SPA:

- 1) It is recommended to drain the spa at least once every 2 months depending on bath load and water clarity.
- 2) The spa should be drained through valve exiting re-circulation pump in the spa equipment room or sump pump.
- 3) Note: Use caution to drain spa in the winter months or rainy season when water table is at its highest. It is possible for the spa to float due to hydraulic pressure from surrounding water table. We advise that you consult with your local spa specialist prior to draining the spa.

C. SPA EQUIPMENT:


- 1) Clean filter cartridge at least once every month, or when needed; i.e., if water clarity does not improve after several days.
- 2) Keep area free and clear from leaves and debris build-up.
- 3) Keep area free and clear from flooding.


D. SPA LIGHT:

1) Spa light has to be on GFCI circuit. It is controlled at spa side with ON/OFF.

E. TILE SERVICING:

1) Contact manufacture when servicing tile or grout. @ (530) 534-9910





DWG TYPE

SPA 1 North

NESPA ENTERPRISES INC.

2800 Richter Ave. Suite C Oroville, CA 95966 Office: (530) 534-9910 Fax: (530) 534-9915 E-Tl

		110000			,	114 112 014 .	
Office: (530) 534-9910	Fax: (530) 534-9915	пери	DWG NAME				SHEET
E-Mail: jim@tiledspas.com	Web Site: www.tiledspas.com	A BURNELS		WYNDHAI	M ANAHEIM	1/4/2017	PAGE 1 OF 1
These drawings, concepts, and details contained herein are the original proprietary designs of NESPA ENTERPRISES INC., developed over many years of experience in the industry and as such							
are protected by the copyright laws of the United States Government. Reproduction of any of the above without written permission to do so by NESPA ENTERPRISES INC., is illegal.							

age <u>S</u>caling:

If printing as a PDF:

None


<u>TiledSpas</u>

SCALE


1/2" = 1'


~

õ 1/4 1/2 3/4 1



are protected by the copyright laws of the United States Government. Reproduction of any of the above without written permission to do so by NESPA ENTERPRISES INC., is illegal.






POOL PIPING LEGEND

- SS = SURFACE SKIMMER: HAYWARD SP-1084, AUTOMATIC w/ EQUALIZER
- EQ = EQUALIZER: AQUASTAR 6HPHAxxx Sumpless Suction Outlet Wall 122 GPM Complies w/ ANSI / ASME A112.19.8 ¢ NSF / ANSI 16-2011 V.G.B.APPROVED.
- BS = BOOSTER SUCTION: AQUASTAR GHPHAxxx Sumpless Suction Outlet Wall 122 GPM Complies w/ ANSI / ASME A112.19.8 ¢ NSF / ANSI 16-2011 V.G.B.APPROVED.
- MD = MAIN DRAIN: AQUASTAR GHPHAxxx Sumpless Suction Outlet Floor 177 GPM Complies w/ ANSI/ASMEA112.19.8 ¢ NSF/ANSI 16-2011 V.G.B.APPROVED.
- J# = JETS: HYDROAIR 10-5100, 1-1/2" WATER, 1-1/2" AIR.
- WI = WATER INLETS: HYDROAIR 10-3500, 1-1/2" WALL TYPE w/ EYEBALL.
- WS = WATER LEVEL SENSOR
- UL = UNDERWATER LIGHT: PENTAIR INTELLIBRITE 5G WHITE LED SPA LIGHT, I 20 V, I 00W
- PB = POOL BOND: PERMA-CAST PB-2008
- CA = CUP ANCHOR: PERMA-CAST -G" BIG BOY SOCKET -USES PW-4C WEDGE

APPROVED

These drawings, concepts, and details contained herein are the original proprietary designs of <u>NESPA ENTERPRISES INC.</u>, developed over many years of experience in the industry and as such are protected by the copyright laws of the United States Government. Reproduction of any of the above without written permission to do so by <u>NESPA ENTERPRISES INC.</u>, is illegal



SCALE

1/2" = 1'

*

WYNDHAM ANAHEIM

If printing as a PDF:

Page Scaling: None

DWG NAME

TiledSpas

nespa

DWG TYPE

SHEET

1/2 3/4

1/4/2017


1


1/4

DATE

Plumbing Layout

PAGE 3 OF 10





SP1084FVE-SKIMMER WITH EQUALIZER VALVE AND FLOAT VALVE ASSEMBLY

A. EQUALIZER-Model SP1078 Equalizer Valve Assembly installs over front port, and is used in conjunction with the SP1082FV Float Valve Assembly. If water level drops below skimmer opening, or if skimmer flow is obstructed, the float will automatically snap shut and the equalizer valve will open. This diverts all flow to the pump from the equalizer line and prevents airlock in the pump- When the pump is shut off, and the water level condition is corrected, the float will rise and the equalizer valve will close, allowing normal skimming operation when the pump is restarted.

B. TO VACUUM Select one convenient skimmer and remove cover. Fill vacuum hose with water and insert onto SP1106 or SP1107 Skim-Vac (not supplied with skimmer) over basket vacuum-plate (not supplied with skimmer). Place Skim-Vac through skimmer opening and over skimmer basket. Turn circulating pump on and proceed with vacuuming. Throttle downflow from other skimmer(s) until desired suction is obtained through vacuum hose.




95966



APPROVED

These drawings, concepts, and details contained herein are the	NESPA ENTERPRISES INC
original proprietary designs of NESPA ENTERPRISES INC. ,	
developed over many years of experience in the industry and as	2800 Richter Ave. Ste. C Oroville, CA 95966
such are protected by the copyright laws of the United States	Office: (530) 534-9910 Fax: (530) 534-9915
permission to do so by NESPA ENTERPRISES INC is illegal	E-Mail:jim@tiledspas.com Web Site:www.tiledspas.com



Office: (530) 534-9910 Fax: (530) 534-9915 E-Mail: jim@tiledspas.com Web Site: www.tiledspas.com

such are protected by the copyright laws of the United States

Government. Reproduction of any of the above without written

ermission to do so by NESPA ENTERPRISES INC., is illegal

DWG NAME WYNDHAM ANAHEIM 1/4/2


SHEET 1/4/2017 PAGE 7 OF 10

BONDING DETAIL




Typical Cup Anchor











TYPICAL NESPA SHELL CUP

Anchor Installation

NOTE:

(6" X 2-1/2")


DETAIL REFLECTS ANCHOR INSTALLATION IN NESPA SHELLS ONLY.


CUP ANCHOR SHALL BE BONDED WITH A SOLID #8 COPPER BOND WIRE AND VERIFIED BY A CALIFORNIA LICENSED ELECTRICAL CONTRACTOR.


Fiberglass

BOND WIRE WILL BE ENCASED AND COVERED IN FIBERGLASS TO PREVENT WATER LEAKAGE THRU SHELL.

BOND WIRE SHALL EXIT AT EDGE OF SPA AND ATTACH TO DECK BONDING GRID.








APPROVED

These drawings, concepts, and details contained herein are the NESPA ENTERPRISES INC. original proprietary designs of NESPA ENTERPRISES INC. developed over many years of experience in the industry and as 2800 Richter Ave. Ste. C Oroville, CA 95966 such are protected by the copyright laws of the United States Government. Reproduction of any of the above without written permission to do so by NESPA ENTERPRISES INC., is illegal

Office: (530) 534-9910 Fax: (530) 534-9915 E-Mail:jim@tiledspas.com Web Site:www.tiledspas.com

Spas	If printing Page <u>Scaling</u> None	as a PDF:	SCALE N/A		DWG TYP	E Bonding Detail
espa	DWG NAME	WYNDHAM	ANAHEIM	DATE 1/4/2017	SHEET	PAGE 8 OF 10



Office: (530) 534-9910

E-Mail:jim@tiledspas.com Web Site:www.tiledspas.com

Government. Reproduction of any of the above without written permission to do so by <u>NESPA ENTERPRISES INC.</u>, is illegal,

APPROVED

DWG TYPE

Page <u>S</u>caling: None < DWG NAME WYNDHAM A

3/4"	' = 1'		Handrail Detail
ANAHEIM	date 4/3/2017	SHEET	PAGE 1 OF 1


POOL BONDING REQUIREMENTS:

1. THE FOLLOWING PARTS SHALL BE BONDED TOGETHER AND CONNECTED TO THE COMMON BONDING GRID.

- A. ALL THE METALLIC PARTS OF THE POOL STRUCTURE INCLUDING COPYING STONES, DECK, PERMANENT PLAY STRUCTURES, PERMANENT EXERCISE STRUCTURES.
- B. ALL METAL FITTINGS WITHIN OR ATTACHED TO THE POOL STRUCTURE
- C. METAL PARTS ASSOCIATED WITH THE POOL WATER CIRCULATING
- SYSTEM, INCLUDING PUMPS, FILTERS, AND HEATERS.
- D. METAL PARTS ASSOCIATED WITH POOL COVERS E. METAL SHEATHED CABLES AND RACEWAYS, METAL PIPING AND ALL FIXED METAL PARTS WITHIN 5 FEET HORIZONTALLY OF INSIDE WALLS

2. BONDING CONDUCTORS SHALL BE MINIMUM #8 SOLID COPPER, INSULATED E.C. SHALL COORDINATE APPROVED CONNECTOR TYPE AND METHOD WITH LOCAL ELECTRICAL AND/ OR POOL INSPECTOR.

3. SPECIFIC MANUFACTURER'S INSTRUCTIONS REGARDING BONDING OR GROUNDING OF POOL EQUIPMENT, WHETHER INDICATED HEREIN OR NOT, SHALL BE STRICTLY FOLLOWED.



INDICATED BY POOL CONTRACTOR OR LOCAL INSPECTION AUTORITY SHALL BE BONDED TO THE COMMON BONDING GRID WITH NO ADDITIONAL COSTS INCURRED BY THE OWNER.


6. THE ELECTRICAL CONTRACTOR SHALL COORDINATE BONDING WITH GENERAL CONTRACTOR.

ermission to do so by NESPA ENTERPRISES INC., is illegal



1/4/2017

PAGE 10 OF 10



E-Mail:jim@tiledspas.com Web Site:www.tiledspas.com



6" ROUND HOCKEY PUCK SUMPLESS SUCTION OUTLET COVER, HYDROAIR/ITT REPLACEMENT

VGB Series



For single or multiple drain use in gunite, steel, fiberglass and tile pools and spas (see installation instructions)

Single - sumpless Floor/wall (2" pipe): 224 GPM at 6.3 fps Floor (11/2" pipe): 177 GPM at 5.9 fps

Floor/wall: 53.3 GPM at 1.5 fps Floor/wall: 35.5 GPM at 1.0 fps

10.4 square inch opening

Trademarked VGB compliance button easily identifies VGB 2008 compliant cover from on deck and underwater

#316 stainless steel screws

Manufactured from superior UV-resistant engineered polymers

All components meet or exceed ANSI/ APSP 16-2011 and NSF/ANSI 50-2009a national standards and ASTM G154 UV testing exposure

See next page for eight adapter plates sold separately, available for sumpless connections to 1022s, 1.5" female adapters, 1.5" and 2" inside and outside slip and threads as well as existing HydroAir wall fittings #10-6015S and 10-6304S (both with brass inserts)

Replace every five years from the date ofinstallation

25 per case

STANDARD COLORS

6HPHA101 - White 6HPHA102 - Black 6HPHA103 - Light Gray 6HPHA104 - Blue 6HPHA105 - Dark Gray


6HPHA108 - Tan

Can replace MaxFlow covers used with p/n 6HA25T20Sxxx

VGB 2008 Compliant

Office: (530) 534-9910

The AquaStar line of suction outlet covers, compliant with the Virginia Graeme-Baker



These drawings, concepts, and details contained herein are the original proprietary designs of NESPA ENTERPRISES INC., developed over many years of experience in the industry and as such are protected by the copyright laws of the United States Government. Reproduction of any of the above without written permission to do so by NESPA ENTERPRISES INC., is illegal.

STANDARD NESPA IN-GROUND INSTALLATION INSTRUCTIONS SET-UP AND EXCAVATION

Prerequisites: Before installing your Nespa spa. You may be required to acquire a permit from your local State, County, and City building dept and or Health department. (Commercial jobs need Health Dept. Approval). Your spa installation must comply with the most current codes. (**Uniform Swimming Pool, Spas & Hot Tub Code 2006** (**USPC 2006**).

Spa drawings: Request from Nespa a current spa specific construction detail, plan and section, spa plumbing detail.

Delivery Access: Clearly determine the method of getting the spa to jobsite and into the hole. This may require the use of a crane, forklift, hoist, backhoe and/or manpower etc.

1) The following instructions are general guidelines and may not apply to your specific jobsite conditions. When excavating for your spa remember to provide for plumbing and light connection clearances. In order to determine how to excavate for your spa or swim spa, measure spas outside dimension (O.D.) and add minimum 3" to all sides. This 3" clearance is to accommodate jet and suction plumbing. This 3" clearance can change or be reduced upon request. Note: skimmer location, this area may have to be larger than 3", if commercial 22".

- 2) Freeze Climates- If the spa is place into a vault (typical of freeze climates) a standard 18" or more of clearance minimum from spa perimeter should be provided. This dead air space is for possible future access to spa plumbing in case of a freeze. Area drain is mandatory. Ask your local installer for his experienced opinion. Do not hesitate to call us because we want to be sure that your installation progresses as smoothly as possible. If you have questions call us. (888) 479-4677.
- 2) **Hole depth** is determined by spa's outside height dimension. This height may vary depending if spa has skids or no skids. The spa lip may be finished or non- finished. How is the perimeter deck elevation transitioning to the spa? Focus on the finish surrounding deck elevations, thickness of the finish material on spa upper horizontal lip, equal to lip or under the spa lip. This material can be tile, stone, concrete or brick.
- 3) **Preplumb** the spa before it goes into the hole. If there are needs for electrical, bonding or control conduits run them as well before dropping in hole. Connect bond wire to niche would be best.

4) Spa should sit on level 3 ¹/₂" thick reinforced concrete pad. Sweep debris off pad prior to dropping in hole.

5) **Install spa** into the hole on top of concrete pad. Use the Eye bolts provided for crane, forklift etc. rigging. Do not hold onto pipes. Use caution with suction and jet plumbing when lowering into hole. DO NOT STRESS FITTINGS! Fill Spa with water and check for leaks prior to backfill.

- 6) Check site reference points for proper spa positioning (i.e., squaring to house, garage, etc.).
- 7) Shim to level spa. Shim with non-compression able material. Re square to house, or ref. point.
- 8) **Dry pack** with cement the gaps that have been created when shimming spa level.
- 9) Connect pipes to tees if spa is preplumb. Installers properly support your new plumbing from stressing spas preplumb fittings. After electrical conduit and bond wire is connected to light niche, water test spa before back filling with sand. NOTE: All Nespa products are water tested prior to leaving factory.

ELECTRICAL:


- 1) All electrical connections to spa or equipment should comply with the most recent national electrical code (NEC), state and local codes.
- 2) Connect electrical conduit to light niche. This work should be done or reviewed by a licensed electrician.
- 3) To install spa light you will need to include inside the PVC conduit to the light niche a solid #8 coated copper wire. (If you are use brass conduit, internal bond wire is not required.) This bond wire should be pulled with the light cord at the same time. This bond wire needs to be attached to the internal bonding lug of the light niche. An approved encapsulate should be applied to bond wire connection in niche.
- 4) An external #8 copper wire shall be connected to the external bonding lug on the rear of the light niche. This copper wire can then be used for additional bonding requirements (i.e., handrails or any other metallic object within 5' of the spa.

PLUMBING:

- 1) When plumbing a Nespa it is important to properly size the plumbing. We highly recommend that you follow the pump manufacturer's pipe sizing requirements and Uniform Swimming Pool, Spas & Hot Tub Code 2006 (USPC 2006). This code book is available at <u>www.IAPMO.org</u> or (909) 472 4100.
- 2) The jet air venturi should be a Hartford loop design adjacent to spa shell and air entry point can be located next to spa or remotely at equipment.
- 3) Fill spa with water and test the system for leaks PRIOR to backfilling with sand.

SAND BACK FILL:

- 1) With water in spa, back-fill around spa perimeter with dry plaster sand and wet wash with hydraulic attachment to hose. Let set for one hour and hydraulic dry again. Be sure water level in spa is at the highest level. Any questions please call us. (888) 479-4677.
- 2) If spa is free standing on elevated deck or a structure, it is important to fill spa with water and load area prior to installing coping or perimeter decking. If spa is installed in a vault situation a area drain is needed.



ase drawings, concepts, and details contained herein are the original proprietary designs of NESPA ENTERPRISES, developed over many years of experience in the pool and spa industry a as such are protected by the copyright laws of the United States Government. Reproduction of any of the above without written permission to do so by NESPA ENTERPRISES, is illegal.

POOL BONDING REQUIREMENTS:

1. THE FOLLOWING PARTS SHALL BE BONDED TOGETHER AND CONNECTED TO THE COMMON BONDING GRID.

- A. ALL THE METALLIC PARTS OF THE POOL STRUCTURE INCLUDING COPYING STONES, DECK, PERMANENT PLAY STRUCTURES, PERMANENT EXERCISE STRUCTURES.
- B. ALL METAL FITTINGS WITHIN OR ATTACHED TO THE POOL STRUCTURE C. METAL PARTS ASSOCIATED WITH THE POOL WATER CIRCULATING
- SYSTEM, INCLUDING PUMPS, FILTERS, AND HEATERS.
- D. METAL PARTS ASSOCIATED WITH POOL COVERS
- E. METAL SHEATHED CABLES AND RACEWAYS, METAL PIPING AND ALL FIXED METAL PARTS WITHIN 5 FEET HORIZONTALLY OF INSIDE WALLS OF POOL AND WITHIN 12 FEET ABOVE MAXIMUM WATER LEVEL OF POOL.
- PLATFORMS, AND DIVING STRUCTURES.

2. BONDING CONDUCTORS SHALL BE MINIMUM #8 SOLID COPPER, INSULATED E.C. SHALL COORDINATE APPROVED CONNECTOR TYPE AND METHOD WITH LOCAL ELECTRICAL AND/ OR POOL INSPECTOR.

3. SPECIFIC MANUFACTURER'S INSTRUCTIONS REGARDING BONDING OR GROUNDING OF POOL EQUIPMENT, WHETHER INDICATED HEREIN OR NOT, SHALL BE STRICTLY FOLLOWED.


4. THE COMMON BONDING GRID SHALL NOT BE CONNECTED TO ANY ELECTRICAL DISTRIBUTION EQUIPMENT.

INDICATED BY POOL CONTRACTOR OR LOCAL INSPECTION AUTORITY SHALL BE BONDED TO THE COMMON BONDING GRID WITH NO ADDITIONAL COSTS INCURRED BY THE OWNER.

6. THE ELECTRICAL CONTRACTOR SHALL COORDINATE BONDING WITH GENERAL CONTRACTOR.

NESPA ENTERPRISES, is illegal.





E-Mail:sales@tiledspas.com Web Site:www.tiledspas.com

NESPA ENTERPRISES, Inc. LIMITED WARRANTY

This LIMITED WARRANTY covering NESPA products is extended to the ORIGINAL PURCHASER-USER BY NESPA ENTERPRISES Inc.(NESPA), 2800 Richter Ave. Unit C California 95966.

NESPA products are thoroughly inspected and tested prior to factory shipment. NESPA warrants to the ORIGINAL PURCHASER-USER that NESPA Spas and Swim Spas will be free of defect in workmanship, accessories and parts, provided said accessories and parts were manufactured by NESPA. NESPA, under this LIMITED WARRANTY, warrants only that its Spas and Swim Spas shall be structurally sound, shall retain their shape, and shall retain water for the warranty period. NESPA warrants the adhesion of tile to fiberglass for a period of three (3) years and structural soundness for ten (10) years. NESPA warrants epoxy grout adhesion for a period of three years. If any such defects appear and are reported within the warranty period, NESPA shall repair or replace such defective parts without charge if an inspection proves the claim.

The provisions of the LIMITED WARRANTY shall not apply to tile cracked, split, chipped or damaged after the product has left the factory, nor damage to tile caused by freezing nor to damage, defect, malfunction or failure to conform with the above warranty provisions where the damage, defect, malfunction or failure to conform was caused during shipment or by distributor or by unreasonable use by ORIGINAL PURCHASER-USER including improper water balance and improper sand pack or support.

This LIMITED WARRANTY shall not apply to any plumbing, equipment, or installation of spas and Swim Spas and shall not apply to any alterations made to or upon NESPA products except alterations made by NESPA employees or NESPA authorized representatives.

This LIMITED WARRANTY is expressly in lieu of all other warranties expressed or implied including the warranties of merchantability and fitness for use and all other obligations or liabilities on NESPA'S part, and NESPA neither assumes nor authorizes any other person to assume for NESPA any other liability in connection with the sale of this NESPA product. This LIMITED WARRANTY shall not apply to this NESPA product or any part thereof which has been subject to accident, negligence, alteration, abuse or misuse. NESPA makes no warranty whatsoever with respect to accessories or parts not manufactured by NESPA.

The term "ORIGINAL PURCHASER-USER" as used in this LIMITED WARRANTY shall be deemed to mean that person for whom the NESPA product is originally installed.

The LIMITED WARRANTY provided herein and the obligations and liabilities of NESPA hereunder are exclusive and are in lieu of, and buyer and original PURCHASE-USER hereby waive all other remedies, warranties, guarantees or liabilities, expressed or implied, arising by law or otherwise (including without limitation and obligations of NESPA with respect to fitness, merchantability, and consequential damages) or whether or not occasioned by NESPA'S negligence.

This LIMITED WARRANTY shall not be extended, altered or varied except by a written instrument signed by NESPA and original PURCHASER-USER.